




It's just 3 steps

Only 2 tools:









Apply **Jeger Oxyd Primer** on a clean, dry, dust-free and degreased surface. Leave it to dry for 4 hours.





Apply a thin layer of **Jeger Oxyd** and leave it to dry for about 8 hours. (If you want to obtain the solid corrosion effect, apply **Jeger Oxyd 3D** with a sponge and then smooth it gently using a plastering trowel). Afterwards, apply **Jeger Oxyd Activator** with provided atomizer. The rust effect will appear in 2-8 hours. You can repeat the rust activation process several times until you achieve the desired effect.







Apply **Jeger Oxyd Protector** after 24 hours. The varnish stops the activation process and protects the decorated surface.







Global Point, ul. Rozwoju 3, Biskupice Podgórne, 55-040 Kobierzyce

