

You can do it yourself in one day!

## It's just 3 steps

Only 2 tools

or concrete slabs effect.

a roller



Apply Jeger
Primer Beton
with a roller





Apply **Jeger Primer Beton** on a clean, dry, dust-free and degreased wall with a paint roller. Leave it to dry for 4 hours.

to obtain a surface imitating raw concrete with characteristic pits





Mix **Jeger Beton** well before use. Do NOT dilute, the product is ready to use. Do NOT mix with other products. Apply a grain-boundary thickness layer with a Venetian trowel and then gently smooth it out. If you want to obtain pits effect, place a Venetian trowel on a freshly applied coating and pull on the trowel fast towards yourself. At the stage of preliminary drying time, smooth gently the entire surface. If you want to change the effect, you can apply another layer after 4 hours and then repeat the process. Leave it to dry for 12 hours.







With a fresh roller apply **Jeger Protector Beton** to the dry surface. After drying the varnish might slightly change the color tone of the Jeger Beton effect.

**Tips:** If you want to create a concrete slab effect, apply **Tape for imitating concrete slabs** to the dried first layer of concrete in the areas separating the slabs from each other. Then apply a second layer of concrete and after approx. 30 minutes remove the tape, obtaining the pattern of the slabs. Gently smooth the entire surface.



**Remember:** If you need to use more than one pack of the product, mix the contents of all the packs together before applying. Check the effect on a small area before applying the varnish to the whole surface. The product is intended for interiors.

 $\frac{7 \text{kg} + \pm 6 \text{m}^2}{14 \text{kg} + \pm 12 \text{m}}$ 

jeger.com



Global Point, ul. Rozwoju 3, Biskupice Podgórne, 55-040 Kobierzyce

